


Unroll the kite and place face down. Insert the two longest spreaders through the casings on the top of the wings, under the center spine and into the pockets in the middle of the wings as shown in the illustration. Insert the shorter spreader under the center spine and into the bottom pockets. Tie your flying line to the loop on the pre-attached bridle found on the front of the kite.

---



Standing with your back to the wind, hold your kite up high pointing the nose skyward. When you feel the pressure of the wind against the kite, let go. As the kite rises, slowly release more line. When possible, have a friend help launch the kite. Tell your friend to stand downwind as you let out 25 feet of line. As the kite is released into the wind, tug on the line. The kite will begin to rise. Slowly release more line as the kite climbs higher into the sky.

If the kite starts to fall, take several quick steps back. This will create lift and the kite will rise again. If the kite goes into a nose dive, it is probably getting too much wind. Let out additional line or step towards the kite to release the pressure. Have fun!

---